

Lymphocyte Absolute CD4 and CD8

Order Name: **T HELP/CYTOTOX**

Test Number: 5603200

Revision Date: 05/24/2023

TEST NAME	METHODOLOGY	LOINC CODE
Lymphocyte Absolute CD4 and CD8	Flow cytometry	

SPECIMEN REQUIREMENTS				
Specimen	Specimen Volume (min)	Specimen Type	Specimen Container	Transport Environment
Preferred	5 mL each (3 mL each)	Whole Blood	EDTA (Lavender) and ACD Sol A/B (Yellow Top)	Room Temperature
Instructions	Collect Whole blood in <b>Both ACD Solution A or B (Yellow Top)</b> and <b>EDTA (Lavender Top)</b> . Keep whole blood, do not centrifuge or refrigerate. <b>Deliver to the laboratory ASAP - Same Day as Collection!</b> <b>Stability:</b> Room Temperature, Yellow-top (ACD-A) or (ACD-B) tube: 2 days Lavender-top (EDTA) tube: 1 day  <b>Collect Monday through Wednesday only. Specimens must be received at Labcorp Oklahoma Inc. by Wednesday afternoon or collect on Monday.</b>			

GENERAL INFORMATION	
Testing Schedule	Testing schedule may vary
Expected TAT	3-5 Days
Clinical Use	Immunophenotype of T lymphocytes.
Performing Labcorp Test Code	096925
Notes	This panel is also known as: T Helper and Suppressor Cells (CD4/CD8)
CPT Code(s)	86359, 86360
Lab Section	Reference Lab